

TRAIL CAM - PERFECT SET UP AND RANGE

Place the sun behind the camera always, otherwise it will shine directly into the lens and affect your photos



www.africanpredator.com
www.africanpredator.com

Camera angled so the laser hits the ground at 12-15m



3 Foot
height or just
above knee
height.

Place bait 5-6m in front of the camera.

This system allows you a perfect angle so the flash will fire pretty high and cover a great area and not over expose itself on the ground, the bait with 5m setting from camera is an ideal range to get animals to feed close so you get good pictures and that angle from camera to 15m is great as it will detect a lot of activity at such an angle.

The camera must be a little higher than knee height for best results; I have proven this over many years of working with cameras.

TRAIL CAMS – Chris Pearson www.cameratrap.co.za / 0835600555

See his website for the latest top quality trail cam models – or see our latest DVD for more info.